Process of installing bar code driver


1、double click， 4BARCODE_2018.1_M-1 and choose "I accept the terms in the license agreement"， click "Next"， as below picture：

2、leave "Installation Directory" as default go "Next"

3　Choose "Run Driver Wizard after unpacking drivers" and go "Next"

4　Choose "Install printer drivers"　click "Next", as below picture

5　After installing the printer drivers　choose the "Other (such as a parallel or serial)", go "Next";

choose the model name "4Barcode 4B-2054L", go "Next";

this sheet no need to operate, go "Next" directly.

PS　No need to set port in driver if the program detected the communication port in this step.

Seagull Driver Wizard

Connect Printer
  The printer should be connected before continuing installation.

How is this printer going to be
- ○ USB
- ○ Network (Ethernet or WiFi)
- ○ Bluetooth
- ● Other (such as Parallel or Serial)

Instructions:
1. Connect your printer to the PC.
2. Turn the printer on.
3. Press Next to continue.

[< Back] [Next] [Cancel]

Seagull Driver Wizard

Specify Printer Model
  The manufacturer and model determine which printer driver to use.

Specify the model of your printer.

Printer Model
4BARCODE 4B-2054H
4BARCODE 4B-2054I
4BARCODE 4B-2054K
4BARCODE 4B-2054L
4BARCODE 4B-2054M
4BARCODE 4B-2054N
4BARCODE 4B-2054TA

Source: F:\New folder
Version: 2021.3.0 (12/01/2021)

[Browse...]

[< Back] [Next >] [Cancel]

Seagull Driver Wizard

Specify Port
  A port is used to connect a printer to the computer.

Specify the port that you are using. If you are connecting using TCP/IP or another port type not listed below, create a new port.

Port	Type
FILE:	Local Port
USB001	USB Virtual printer port

[Create Port...] [Configure Port...]

[< Back] [Next >] [Cancel]

6 Default name of printer is "4BARCODE4B-2054L" Choose "Usethis printer as the default printer" click "Next" as below picture:

7 Completing driver installation click "Finish" as below picture:

8、Complete the installation of driver "4BARCODE 4B-2054L", click

"Close", Asbelowpicture:



9 After installed drivers click"Start"→"Settings"→ "Devices"→"Printers and Scanners" choose 4BARCODE4B-2054L，click "manage"

🖥️ **System** Display, sound, notifications, power	📇 **Devices** Bluetooth, printers, mouse	📱 **Phone** Link your Android, iPhone
🌐 **Network & Internet** WiFi, flight mode, VPN	🖊️ **Personalisation** Background, lock screen, colours	☰ **Apps** Uninstall, defaults, optional features
👤 **Accounts** Your accounts, email, sync, work, family	🕐 **Time & Language** Speech, region, date	⊗ **Gaming** Xbox Game Bar, captures, Game Mode
⏲️ **Ease of Access** Narrator, magnifier, high contrast	🔍 **Search** Find my files, permissions	🔒 **Privacy** Location, camera, microphone
🔄 **Update & Security** Windows Update, recovery, backup		

← Settings

⌂ Home

Find a setting 🔍

Devices

🖳 Bluetooth & other devices

🖨️ **Printers & scanners**

🖱️ Mouse

⌨️ Typing

🖊️ Pen & Windows Ink

⏯️ AutoPlay

🔲 USB

Printers & scanners

Add printers & scanners

➕ Add a printer or scanner

Printers & scanners

📄 4BARCODE 4B-2054L

🖨️ Fax

📄 Microsoft Print to PDF

📄 Microsoft XPS Document Writer

🖨️ 输出WPS PDF

← Settings

⌂ Home

Find a setting 🔍

Devices

🖳 Bluetooth & other devices

🖨️ Printers & scanners

🖱️ Mouse

⌨️ Typing

🖊️ Pen & Windows Ink

⏯️ AutoPlay

🔲 USB

Printers & scanners

Add printers & scanners

➕ Add a printer or scanner

Printers & scanners

📄 4BARCODE 4B-2054L

    Open queue   **Manage**   Remove device

🖨️ Fax

📄 Microsoft Print to PDF

📄 Microsoft XPS Document Writer

10 Click the "Printer properties" and then Click "Print a test page" and the printer will print a test page.

The drive has been installed successfully when test page is printed. Thanks for your support